



## Password OVP V5.0.17 program is **unjo2015** ( small letters)


Installation help for OVP-V.17 program. Compatible with Windows 7 and newer windows versions.




Press: NEXT




Press : NEXT



IF you have older versions of OVP-V program in your computer, you get this message. It is always best to make a new folder and put this program there.




Press: NEXT



Press: **NEXT** ( if you have older OVP-V version in your computer)

**NOTE!** If don't have earlier versions of OVP-V programs in your computer, select: **Install/update DFU –driver** and **Install/update serial port driver**, then press **NEXT**



Press: **INSTALL**

Open the **OVP-V** program - Press **DISCONNECT** in **START** menu-  
Connect your actuator to computer with USB/USB mini cable- Go to **OPTIONS** menu,  
Select: **OVP SETTINGS** in curtain menu- Select **COM ( meaning USB port)** port you are connected in **CONNECTIONS**  
push button- Select **NORMAL** in **FONT SIZE** for better resolution. Press **SAVE**. Press **CONNECT**. Now you are able to  
make required settings in your actuator. Next time you connect your computer to actuator, choose same USB port and  
open your OVP-V program. Program will make connection to your actuator and find your actuator type and settings.